


Hauptplatte / Main board D12



Hauptplatte / Main board D14


Hauptplatte
Main board
PL 3269 D12
Chip

T-Line (3265)
Lübeck C30
Luxembourg C30
Augsburg C30
Dublin C30
Boston C30
Minnesota DJ30
Ontario DJ30

FunLine2 (3265)
Düsseldorf C50
Bologna C50
Colorado DJ50
Carolina DJ50

FunLine2 (3269 D12)
Sylt CD50
Modena CD50
Dakota DJ50

T-Line (3269 D12)
Kiel CD30
Lausanne CD30
Alicante CD30



D12


**Hauptplatte
Main board
PL 3269 D12**

T-Line (3265)
Lübeck C30
Luxembourg C30
Augsburg C30
Dublin C30
Boston C30
Minnesota DJ30
Ontario DJ30

FunLine2 (3265)
Düsseldorf C50
Bologna C50
Colorado DJ50
Carolina DJ50

FunLine2 (3269 D12)
Sylt CD50
Modena CD50
Dakota DJ50

T-Line (3269 D12)
Kiel CD30
Lausanne CD30
Alicante CD30



D12

**Hauptplatte
Main board
PL 3269 D12**

D12


Hauptplatte
Main board
PL 3269 D14
Chip

T-Line (3265)
Lübeck C30
Luxembourg C30
Augsburg C30
Dublin C30
Boston C30
Minnesota DJ30
Ontario DJ30

FunLine2 (3265)
Düsseldorf C50
Bologna C50
Colorado DJ50
Carolina DJ50

FunLine2 (3269 D14)
Sylt CD50
Modena CD50
Dakota DJ50

T-Line (3269 D14)
Kiel CD30
Lausanne CD30
Alicante CD30



D14

**Hauptplatte
Main board
PL 3269 D14**


T-Line (3265)
Lübeck C30
Luxembourg C30
Augsburg C30
Dublin C30
Boston C30
Minnesota DJ30
Ontario DJ30

FunLine2 (3265)
Düsseldorf C50
Bologna C50
Colorado DJ50
Carolina DJ50

FunLine2 (3269 D14)
Sylt CD50
Modena CD50
Dakota DJ50

T-Line (3269 D14)
Kiel CD30
Lausanne CD30
Alicante CD30

zu Schaltbild Funline2 / T-Line D+EU 8 622 402 764




D14

**Hauptplatte
Main board
PL 3269 D14**


D14

FunLine2
 Düsseldorf C50
 Bologna C50
 Sylt CD50
 Modena CD50
 Colorado DJ50
 Carolina DJ50
 Dakota DJ50




Schalterplatte / Key board A09

**Schalterplatte
Key board
PL 3273 D09
B + Chip**



D09





**Schalterplatte
Key board
PL 3273 D09
Chip**




D09

halterplatte / Key board

zu Schaltbild Funline2 / T-Line D+EU 8 622 402 387




LITERPLATTE KEYBOARD




PL 3271 D06

HAUPTPLATTE ↓ **MAIN BOARD**




Schalterplatte
Key board
PL 3271 D07




Chalterplatte / Key board

PLATTE ARD




UPTPLATTE
AIN BOARD

**BP4-Steuerplatte
P4 Control board
PL 0902 A06
Chip**



**BP4-Steuerplatte
P4 Control board
PL 0902 A06
Chip**



A diagram showing a vertical black line representing a track. A horizontal line extends from the right side of the track, labeled "TRACK" at its end.

